## ALBIS ECS-F

ORDER NUMBER	PART NUMBER	DESCRIPTION
		ECS-F SYSTEM EXTENSIONS
BCFB1604	F32-16-4	ECS-F with16 Lines and 4 Connections BGR1/3 rack, built in Cabinet
BCFB1608	F32-16-8	ECS-F with16 Lines and 8 Connections BGR1/3 rack, built in Cabinet
BCFB2408	F32-24-8	ECS-F with 24 Lines and 8 Connections BGR1/3 rack, built in Cabinet
BCFB2412	F32-24-12	ECS-F with 24 Lines and 12 Connections BGR1/3 rack, built in Cabinet
BCFB3212	F32-32-12	ECS-F with 32 Lines and 12 Connections BGR1/3 rack, built in Cabinet
BCFB3216	F32-32-16	ECS-F with 32 Lines and 16 Connections BGR1/3 rack, built in Cabinet

## ALBIS ECS-F

ORDER NUMBER	PART NUMBER	DESCRIPTION
		ECS-F LINE MODULS
BCFB2109	S1021-Y9-A	IFL Interface Logic for two Interface Moduls
BCFB2106	S1021-Y6-B	IF-HF F 4-Wire Interface for two E&M Lines
BCFB2107	S1021-Y7-A	IF-TS F 2-Wire Interface for two Subscriber Lines
BCFB2117	S1021-A17-A	IF-TCS Interface for two Trunk Call Selectors
BCFB2118	S1021-Y18-B	IF-HT Interface for one E&M/Subscriber Line
		ECS-F CENTRAL MODULS
BCFB2101	S1021-Y1-A	ZTU Central Clock Supply
BCFB2102	S1021-Y2-A	KDS M801E Customer Data Memory 2kB
BCFB2103	S1021-Y3-B	8KF Switching Matrix 8KF (8x8)
BCFB2131	S1021-Y3-B1	4KF Switching Matrix 4KF (8x4)
BCFB2104	S1021-Y4-B	KEL Switching Matrix Logic
BCFB2105	S1021-Y5-B	KEU Column Terminator
BCFB2116	S1021-Y16-A	LT Line Driver
BCFB2119	S1021-Y19-A	SPE F Memory Extension

## ALBIS ECS-F

ORDER NUMBER	PART NUMBER	DESCRIPTION
BCEC3212	S1032-K12-A	BF-ECS Servicing Unit
BCEC3016	S30810-K9516-X	RG Ringing Generator 25 Hz
BCEC30A3	S30810-Q9529-A3	GAA3 DC/DC Converter 48V/5V 6A
BCEC30B2	S30810-Q9529-B2	GAB2 DC/DC Converter 48V/12V 2A
BCEC30D1	S30810-Q9529-D1	GAD DC/DC Converter 48V/8V 3A
BCEC3066	S30810-Q166-X1	CPU M801C Central Processor Unit incl. Software
		MAINTENANCE
BCFB2161	S1021-K61-A	CASE F/FX Servicing Case for ECS-F/FX
BCFB2162	TEST F/FX	Testcable HF for ECS-F/FX
BCFB2163	NFN-49501	Subscriber Overvoltage Protection
BCFB9900	SW ECS-F	System Software for ECS-F loaded in EPROM's
BCFB9910	KD ECS-F	Customer Data defined by user loaded in EPROM's
BCFB99xx	KDSxx	ECS-F Initialization EPROM KDS08, KDS16, KDS32, KDS48
BCFB9950	ECSFBAT	Ni-Cd Battery for KDS ECS-F